


Important Information

1

To open, loosen knobs and unfold metal rods.



2

Pull open then place hand near pivot and push down on the extended end.




Caution: Keep fingers away from moving parts






3

Continue to push until the extended end locks into place.



4

To fold perform above steps in reverse.



If you have any questions about how to fold the Canopy, please call our Customer Service Department at 888-266-8243 or (310) 618-0111.