


Important Information




1

Release the Rear Lock Brace by lifting up on the center of brace **(A)**.




2

Press in the silver snap button on the Rear Lock Brace **(B)** and **(C)** then pull the lock brace off of the housing **(D)**.




3

Pull shoulder strap through the upholstery, reposition to the desired height, and reinsert it back through the seat upholstery **(E)**. Slide the shoulder harness loop on to the Rear Lock Brace **(F)**.






Note:

The shoulder straps should be positioned in slots that are slightly above the shoulders of the child, and as the child grows, they should be moved to maintain a height above the shoulder level.



4


Reinsert the Lock Brace onto the housing **(G)** by pushing it with the palm of your hand **(H)**. Lock the Rear Lock Brace by pressing down on the Rear Lock Brace **(I)**.




(continued on reverse)

Adjusting the Pelvic Belt Straps

1




To Tighten:
Tighten the pelvic belt straps by pulling on the loop located at the end of the strap **(A)**.




To Loosen:
Loosen the pelvic belt strap by pushing the gray button on the Strap Adjustment Lock and pulling on the end of the strap closest to the buckle **(B)**.

Adjusting the Crotch Strap

1



To Tighten:
Tighten the Crotch Strap by pulling on the loop located at the end of the strap **(A)**.



To Loosen:
Loosen the Crotch Strap by pushing the gray button on the Strap Adjustment Lock and pulling **(B)**.